

For the competent person

Installation and maintenance instructions



auroSTEP plus

VMS 8, VIH S1 .../4 B, VIH S2 .../4 B

EXPen

Publisher/manufacture

Vaillant GmbH

Berghauser Str. 40 ■ D-42859 Remscheid
Tel. +49 21 91 18-0 ■ Fax +49 21 91 18-28 10
info@vaillant.de ■ www.vaillant.de



Contents

Contents

1	Safety	3	9.5	Replacing the mains connection line	21
1.1	Action-related warnings	3	9.6	Checking and replacing solar fluid	21
1.2	Intended use	3	9.7	Checking the magnesium protection anode and cleaning the cylinder's inner vessel	22
1.3	General safety information	3	9.8	Checking the expansion relief valve	22
1.4	Regulations (directives, laws, standards)	5	9.9	Checking and replacing the electrical heating rod	22
1.5	Requirements for lines	5	9.10	Additional tests/tasks	22
2	Notes on the documentation	6	9.11	Completing inspection and maintenance work	23
2.1	Observing other applicable documents	6	10	Decommissioning	23
2.2	Storing documents	6	10.1	Temporary decommissioning	23
2.3	Applicability of the instructions	6	10.2	Permanently decommissioning	23
3	Product description	6	11	Recycling and disposal	23
3.1	System performance data	6	11.1	Recycling and disposal	23
3.2	Functional elements of the VMS 8	6	11.2	Disposing of solar fluid	23
3.3	Functional elements of the safety group	7	12	Customer service	23
3.4	Functional elements of the VMS 8 with electrical heating rod	7	Appendix	24	
3.5	Information on the identification plate	7	A	Installer level – Overview	24
3.6	Serial number	7	B	Detecting and rectifying faults	25
3.7	CE label	7	C	Connection diagram	26
4	Operation	7	D	Technical data	27
4.1	Operating concept of the solar charger	7	E	Maximum daily hot water output	27
5	Installation	8			
5.1	Transport and positioning	8			
5.2	Complying with clearances and installation clearances	9			
5.3	Noise	9			
5.4	The rules for laying the pipelines for the solar circuit must be followed	9			
5.5	Connecting the solar charging system and cylinder	10			
5.6	Removing the front casing	10			
5.7	Carrying out the hydraulics installation	10			
5.8	Carrying out the electrical installation	12			
5.9	Completing installation	14			
6	Start-up	14			
6.1	Checking and treating the heating water/filling and supplementary water	15			
6.2	Filling and purging the system	16			
6.3	Running through the installation assistant	17			
6.4	Test menu	18			
6.5	Configuration	18			
6.6	Documenting start-up	19			
7	Handing over to the operator	19			
8	Rectifying faults	20			
8.1	Detecting and rectifying faults	20			
8.2	Restarting the solar pump	20			
9	Inspection and maintenance	20			
9.1	Inspection and maintenance check-list	20			
9.2	Observing inspection and maintenance intervals	20			
9.3	Procuring spare parts	20			
9.4	Preparing inspection and maintenance work	21			



1 Safety

1.1 Action-related warnings

Classification of action-related warnings

The action-related warnings are classified in accordance with the severity of the possible danger using the following warning signs and signal words:

Warning symbols and signal words



Danger!

Imminent danger to life or risk of severe personal injury



Danger!

Risk of death from electric shock



Warning.

Risk of minor personal injury



Caution.

Risk of material or environmental damage

1.2 Intended use

There is a risk of injury or death to the user or others, or of damage to the product and other property in the event of improper use or use for which it is not intended.

The product is used to store and provide hot water, and to regulate its distribution. This hot water is generated thanks to the solar technology. The product must only be operated in the solar circuit with Vaillant ready-mixed solar fluid. The product was specially developed for Vaillant **auroTHERM** (VFK .. V) solar collectors.

Intended use includes the following:

- observance of accompanying operating, installation and servicing instructions for the product and any other system components
- compliance with all inspection and maintenance conditions listed in the instructions.

Any other use that is not specified in these instructions, or use beyond that specified in this document shall be considered improper use. Any direct commercial or industrial use is also deemed to be improper.

Caution.

Improper use of any kind is prohibited.

1.3 General safety information

1.3.1 Risk of death due to lack of safety devices

The schematic drawings included in this document do not show all safety devices required for correct installation.

- ▶ Install the necessary safety devices in the system.
- ▶ Observe the applicable national and international laws, standards and guidelines.

1.3.2 Risk of death from electric shock

There is a risk of death from electric shock if you touch live components.

Before commencing work on the product:

- ▶ Disconnect the product from the power supply by switching off all power supplies (electrical partition with a contact opening of at least 3 mm, e.g. fuse or line protection switch).
- ▶ Secure against being switched back on again.
- ▶ Wait for at least 3 minutes until the capacitors have discharged.
- ▶ Check that there is no voltage.

1.3.3 Risk of death due to over-voltage

During a storm, components such as solar lines and heating water pipes may carry a charge from a lightning strike. Touching the components may result in serious personal injury.

- ▶ Earth the solar circuit to provide equipotential bonding and overvoltage protection.
- ▶ Secure the pipe clamps for earthing to the solar lines.
- ▶ Connect the pipe clamps for earthing to a busbar using 16 mm² copper cable.

1.3.4 Risk of burns from components through which solar fluid flows and heating water pipes

In solar mode, components through which solar fluid flows, such as collectors and solar lines, as well as the heating water pipes, reach extremely high temperatures. Touch-



1 Safety



ing these components may result in serious personal injury.

Hot vapour may be emitted from the expansion relief valve.

- ▶ Only touch these components if you have first checked the temperature.
- ▶ To prevent injuries caused by hot parts, carry out work, such as the installation and replacement of collectors or collector parts, when the weather is cloudy and overcast.
- ▶ Alternatively, if the weather is sunny, carry out this work at the beginning or end of the day or with the collector covered.

1.3.5 Risk caused by inadequate qualifications

The following work must only be carried out by competent persons who are sufficiently qualified to do so:

- Installation
- Disassembly
- Installation
- Start-up
- Maintenance
- Repair
- Decommissioning
- ▶ Observe all instructions that are included with the product.
- ▶ Proceed in accordance with the current state of technology.
- ▶ Observe all applicable directives, standards, laws and other regulations.

1.3.6 Danger caused by improper operation

Improper operation may present a danger to you and others, and cause material damage.

- ▶ Carefully read the enclosed instructions and all other applicable documents, particularly the "Safety" section and the warnings.

1.3.7 Danger due to malfunctions

Ensure that the solar system and heating installation are in a technically perfect condition.

- ▶ Ensure that no safety or monitoring devices have been removed, bridged or disabled.

- ▶ Immediately rectify any faults and damage that may affect safety.
- ▶ At lengths of over 10 m, route 220-240 V supply lines and sensor and/or bus lines separately.

1.3.8 Risk of material damage caused by using an unsuitable tool

- ▶ Use the correct tool to tighten or loosen screw connections.

1.3.9 Damage to the environment as a result of leaking solar fluid

Leaking solar fluid may enter the groundwater and potentially contaminate drinking water.

- ▶ Ensure that any solar fluid that is emitted during installation and maintenance or repair work is captured.
- ▶ Dispose of the solar fluid in an environmentally friendly manner in accordance with national regulations.

1.3.10 Product damage due to an unsuitable installation site

The product can be damaged if it is installed in an unsuitable room.

- ▶ Only install the product in a dry room that is free of dust and corrosive or highly flammable gases.
- ▶ In particular, when installing directly below an uninsulated roof, care must be taken to ensure that the air supply to the product is guaranteed and that heat cannot build up at the installation site.
 - In summer, the temperature at the installation site must not be considerably higher than the outside temperature.

1.3.11 Damage to building as a result of leaking solar fluid

Leaking solar fluid may cause damage to the building structure.

- ▶ Disconnect the solar charger from the power mains.
- ▶ Fix the leaks in the solar system.
- ▶ Fill the solar system with solar fluid.
- ▶ Switch on the power supply to the solar charger.





1.3.12 Risk of material damage caused by frost

- ▶ Install the product in a frost-free room.
- ▶ Use only solar fluid from the manufacturer.
 - By filling the system with solar fluid from the manufacturer, you can achieve frost protection of up to approx. -28 °C. However, at outside temperatures lower than -28 °C, there is no immediate risk of frost damage, because the explosive effect of the water is reduced.

1.4 Regulations (directives, laws, standards)

- ▶ Observe the national regulations, standards, guidelines and laws.

1.5 Requirements for lines

- ▶ Use standard commercial lines for the wiring.

Minimum cross-section

220-240 V supply line	$\geq 1.5 \text{ mm}^2$
Sensor line (extra-low voltage)	$\geq 0.75 \text{ mm}^2$
Bus line (extra-low voltage)	$\geq 0.75 \text{ mm}^2$

Maximum line length

Sensor lines	$\leq 50 \text{ m}$
Bus lines	$\leq 300 \text{ m}$

Sensor and bus lines must not run parallel to 220-240 V lines over a length of more than 10 m.

- ▶ The supply lines must be laid separately.
- ▶ Secure all supply lines using the cable brackets that are integrated into the product.
- ▶ Do not use the free terminals of the products as supports for other wiring.
- ▶ Install the system components in dry rooms.

2 Notes on the documentation

2 Notes on the documentation

2.1 Observing other applicable documents

- ▶ You must observe all the operating and installation instructions included with the system components.

2.2 Storing documents

- ▶ Pass these instructions and all other applicable documents on to the system operator.

2.3 Applicability of the instructions

These instructions apply for the following only:

Product – Article numbers

	Article number
VMS 8	0010017732
VIH S1 250/4 B	0010017708
VIH S2 250/4 B	0010017709
VIH S1 350/4 B	0010017710
VIH S2 350/4 B	0010017711

3 Product description

3.1 System performance data

The system should be dimensioned in such a way that the volume of the cylinder is sufficient for two days. In areas where the sun shines brightly, we recommend that you use a cylinder with a lower volume in order to prevent frequent stagnation in the system.

The solar system has been tested with radiation exposure over a collector surface of 1000 W/m².

The system's degree of solar cover depends on the relationship between the collector surface and the cylinder surface, on the geographical circumstances (the collector surface's country and alignment), and on the type of cylinder (monovalent or bivalent). If the system has been designed and installed correctly, the guideline value is up to 3 kWh/m²d (one collector = 2.3 m²).


The consumption of electrical energy for 2000 hours in solar mode is 149.5 kWh.

The frost protection function is controlled via a post-heating installation and/or via the internal electrical heating rod. The minimum temperature of 10 °C can be set in the DIA system and can then be used as a switch-on threshold in the cylinder (→ DIA system, see operating instructions).

The maximum daily hot water output can be found in the table in the appendix:

Maximum daily hot water output (→ Page 27)

3.2 Functional elements of the VMS 8



- | | |
|--|---|
| 1 Heating flow connection (for VIH S2 250/4 B and VIH S2 350/4 B only) (1") | 7 Air vent pot incl. stop cock and air vent bolt, solar supply pipe |
| 2 Cylinder dry pocket for the cylinder temperature sensor (for VIH S2 250/4 B and VIH S2 350/4 B only) | 8 Solar controller |
| 3 Heating return connection (for VIH S2 250/4 B and VIH S2 350/4 B only) (1") | 9 Safety overheat cut-off device |
| 4 Circulation connection (1") | 10 Retainer for the front casing |
| 5 Magnesium protection anode | 11 Safety group |
| 6 Cold water connection (3/4") | 12 Solar pump |
| | 13 Solar circuit filling and draining connection |
| | 14 Solar return temperature sensor |
| | 15 Solar return cylinder connection |
| | 16 Cylinder drain valve |

- 17

Solar circuit purging valve
- 18


Solar supply pipe temperature sensor
- 19

Connection for the electrical heating rod
- 20

Solar supply pipe cylinder connection
- 21

Hot water connection

3.3 Functional elements of the safety group



- 1

Expansion relief valve with connection for the discharge line
- 2

Connection for the solar expansion vessel
- 3

Pressure gauge
- 4

Filling valve inlet
- 5


Filling valve outlet
- 6

Non-return valve with inspection window
- 7

Stop cock
- 8

Solar return connection

3.4 Functional elements of the VMS 8 with electrical heating rod



- 1

3-way valve
- 2

Electrical heating rod
- 3

Electronics box for the electrical heating rod

3.5 Information on the identification plate

The identification plate is attached at the factory so that it is above the safety cut-out. The identification plate contains the following information:

Information on the identification plate	Meaning
VMS 8	For identification
P _{max}	Maximum solar output
m	Weight
V _{s prim}	Solar circuit volume
T _{max prim}	Solar circuit maximum temperature
P _{max prim}	Solar circuit maximum operating pressure

3.6 Serial number

The 10-digit article number for the product (solar charging system and cylinder) can be found in the serial number. The seventh to sixteenth numbers constitute the article number. The serial number is located on the identification plates for the solar charging system and the cylinder. You can also view the serial number for the solar charging system in the display (→ **Operating instructions**).

3.7 CE label



The CE label shows that the products comply with the basic requirements of the applicable directives as stated on the identification plate. The declaration of conformity can be viewed at the manufacturer's site.

4 Operation

4.1 Operating concept of the solar charger

The solar charger is equipped with a digital information and analysis system (DIA system). If additional settings are required, which have not been configured using the installation assistant (see Start-up (→ Page 14)), additional parameters can be viewed and modified using the DIA system. The **operating instructions** describe the operating concept and how to operate product. The read-off and setting options at the operator level are also described in the → **Operating instructions**.

4.1.1 Calling up the installer level



Caution.
Risk of damage caused by incorrect handling.
Incorrect settings at installer level may cause damage to the solar plant.
► You must only access the installer level if you are an approved competent person.

5 Installation



Note

The installer level is password-protected to prevent unauthorised access, as incorrect parameter settings at this level can cause functional faults and damage to the solar plant.

1. Press and at the same time.
 - ◁ The following menu appears in the display.
2. Use the or button to scroll until the **Installer level** menu point appears.
3. Press to select the menu point.
 - ◁ In the display, the text **Enter code** appears along with the value **00**.
4. Use or to set the value 17 (code).
5. Press to confirm the code that has been entered.
 - ◁ The installer level appears with a selection of menu points.



Note

In the following sections, path details at the start of an instruction specify how you can access the relevant function, e.g. **Menu** → **Installer level** → **Test menu** → **Check programmes**.




Note

If you exit the installer level and then access it again within 15 minutes, you do not have to enter the code again.

5 Installation


5.1 Transport and positioning

5.1.1 Transporting the cylinder in the packaging



- Use suitable transport aids to transport the cylinder to the installation site, e.g. a sack truck.

5.1.2 Transporting the cylinder without any packaging



1. Remove the top piece of polystyrene and the cardboard slide box.
2. Lift the cylinder (1) out from the bottom piece of padding (2).
3. Set the sack truck in front of the pallet and load the cylinder onto it.

5.1.3 Scope of delivery

The cylinder and the solar charging systems are each delivered in one packaging unit.


Quantity	Description
1	Cylinder
1	Solar charger
1	Cylinder temperature sensor (for VIH S2 250/4 B and VIH S2 350/4 B only)
1	Enclosed fastening material
1	C1/C2 connection cable (for VIH S2 250/4 B and VIH S2 350/4 B only)
1	Collector temperature sensor

- Check that the scope of delivery is complete.


5.2 Complying with clearances and installation clearances

5.2.1 Product dimensions and connection dimensions

5.2.1.1 VIH S1 250/4 B and VIH S2 250/4 B



5.2.1.2 VIH S1 350/4 B and VIH S2 350/4 B



5.2.2 Installation clearance

- Select an installation site for the cylinder unit that means that you have approx. 35 cm of space above the cylinder so that the magnesium protection anode can be replaced.

5.3 Noise

Noise occurs during operation. The volume depends on the design of the solar circuit. Although the noises are relatively quiet, they may be considered a nuisance.


- Install the product in a sound-proof room (e.g. plant room or boiler room).

5.4 The rules for laying the pipelines for the solar circuit must be followed

- To prevent energy losses, provide all of the pipelines in the solar circuit with heat insulation.
- To prevent heat losses, install the product as close as possible to the collector field; a minimum clearance of 3 m must be maintained.
- Install the product in a frost-proof room.
- Do not lay more connection lines than allowed. Please refer to the planning information.


5 Installation

5.5 Connecting the solar charging system and cylinder



1. Remove the protective caps from the connectors (1).
2. If required, grease the O-rings on the connectors (1) again to facilitate the installation.
3. Slide the solar charging system and the cylinder connections onto the connectors.
4. Use the enclosed clips (2) to secure the cylinder connections.
5. Use the four screws (3) to secure the solar charging system.

5.6 Removing the front casing



1. Take hold of the recessed handle at the bottom edge of the white panel (A).
2. Pull the lower edge of the panel forwards and remove the panel by pulling it upwards (A).
3. Undo the screw (B) (do not remove it completely).
4. Pull the front casing forwards and off (C).

5.7 Carrying out the hydraulics installation



Caution.

Risk of damage caused by contaminated lines.

Foreign bodies such as welding/soldering remnants, sealing residue or dirt in the pipelines may cause damage to the product.

- Before the installation, flush the solar circuit's pipelines thoroughly.
- Ensure that no water remains in the solar circuit after it has been rinsed out.



Caution.

Risk of damage caused by leaks.

Mechanical tension on supply lines may cause leaks and damage to the product.

- Avoid mechanical tension on supply lines.

- The work described in this section must only be carried out by a competent person.



Note

Seals made of rubber-like materials may be subject to plastic deformation, which can lead to pressure losses. We recommend using seals made of a paste-like fibre material.

5.7.1 Installing drinking water pipes

To connect the drinking water pipes to the cylinder, Vaillant offers various piping sets as accessories for surface or flush installation.

The piping, which is to be set up on-site, requires the following components:

- Hot water thermostat mixer
- Hot water expansion vessel (if required)
- Pressure reducer in the cold water pipe (if required)
- Non-return valve in the heating circuit (if required)
- Service valves
- Legionella protection pump (if required)

The hot water thermostat mixer ensures that the hot water from the cylinder is mixed with cold water to produce water with a maximum temperature between 30 and 70 °C as required. When starting up the solar system, if you set the hot water thermostat mixer to the required maximum flow temperature, this maximum flow temperature is retained at the hot water draw-off points.

- ▶ When installing the supply lines, observe the installation manual that is included with the relevant accessories.
- ▶ To guarantee effective scald protection, set the thermostat mixer to < 60 °C and check the temperature at a hot water draw-off point.

5.7.2 Installing a discharge line

1. Install the discharge line with a continuous downwards incline in a frost-free environment.



Note

Water can escape from the discharge line at any time.

2. Ensure that the size of the discharge line corresponds to the size of the expansion relief valve that has been checked with the type sample.
3. Ensure that the discharge line has a maximum of two elbows and a maximum length of 2 m.
4. Ensure that the discharge line is always open.
5. Install the discharge line in such a way that, when discharging the hot water or vapour that is generated, no persons are endangered by this.
6. Actuate the drainage device on the expansion relief valve regularly in order to remove any limescale formation and ensure that the device is not blocked.

5.7.3 Connecting the secondary circulation line (optional)

Since standby energy consumption results from a secondary circulation line, this should only be connected if the hot water network is widely dispersed. If a secondary circulation line is required, you must equip the circulation pump with a timer in accordance with the heating system regulations.

- ▶ If required, connect the secondary circulation line to the cylinder.

If a hot water thermostat mixer is integrated into an existing circulation section, scald protection is not guaranteed.

- ▶ Install the hot water thermostat mixer downstream from the circulation section.

5.7.4 Installing the solar in-line vessel and the solar expansion vessel



Caution.

Risk of damage to the solar expansion vessel

Hot solar fluid may damage the diaphragm of the solar expansion vessel.

- ▶ Use a solar in-line vessel.

1. If required, install a solar in-line vessel.
2. Install a solar expansion vessel.



Note

You can determine the pre-charge pressure of the solar expansion vessel on the system from 50 to 400 kPa (0.5 to 4.0 bar).

3. Alternatives 1 / 2

Conditions: Size of the solar expansion vessel: 18 l, 25 l or 35 l

- ▶ Install the solar expansion vessel on the wall.

3. Alternatives 2 / 2

Conditions: Size of the solar expansion vessel: 50 l, 80 l or 100 l

- ▶ Set up the solar expansion vessel.
4. Cut an opening in the solar charging system's casing in order to guide the line to the solar expansion vessel out from the casing. The opening to use is marked.
 - If an electrical heating rod has been installed, use one of the two upper markings to cut out the opening.
 - If no electrical heating rod has been installed, use one of the two lower markings to cut out the opening.
 5. At a later point, guide the line for the solar expansion vessel out from the side of the casing.

5.7.5 Connecting the discharge line to the safety group



Warning.

Risk of personal injury and material damage caused by incorrect installation!

Solar fluid emitted from the discharge line on the safety group may cause serious scalding.

- ▶ Install the discharge line on the safety group in such a way that no-one is at risk.
- ▶ Route a temperature-resistant discharge line with a downward gradient to a collecting container suitable for solar fluid.


5 Installation

- ▶ Set up the collecting container in such a way that it cannot tip over.
- ▶ Route the discharge line in such a way that no liquid can remain in the discharge line.
- ▶ Make sure that the collecting container is visible.




Note

An empty Vaillant solar fluid container can be used as a collecting container.



1. Install the discharge line (1) as shown.
2. Cut two openings in the solar charging system's casing in order to guide the discharge line out from the casing. The openings that are to be used are marked.
 - If an electrical heating rod has been installed, use the two upper markings to cut out the openings.
 - If no electrical heating rod has been installed, use the two lower markings to cut out the openings.
3. At a later point, guide the discharge line out from the side of the casing.

5.7.6 Connecting the solar circuit



- ▶ Install the flow (1) and return (2) as shown.

5.8 Carrying out the electrical installation



Danger!

Risk of death from electric shock!

A continuous voltage is always present on the mains connection terminals L and N.

- ▶ Before starting work, disconnect the product from the power mains by de-energising the product using an all-pole partition with a contact opening of at least 3 mm (e.g. fuses or power switches).



Danger!

Risk of death from electric shock as a result of an improper electrical connection!

An improper electrical connection may negatively affect the operational safety of the product and result in material damage or personal injury.

- ▶ The electrical installation must be carried out by a suitably qualified competent person who is responsible for complying with the existing standards and directives.



Caution.

Risk of damage to the electrical lines as a result of high temperatures.

The electrical lines may be damaged by the high temperatures from the solar fluid that flows through the copper pipes.


- ▶ Make sure that the electrical lines are not positioned directly next to the pipes through which the solar fluid flows.

- For the electrical installation of the product, observe the technical connection requirements for connecting to the low-voltage network of the power supply network operator.


5.8.1 Connecting the legionella protection pump or bypass diverter valve

Preliminary work

- Remove the front casing. (→ Page 10)



1. Undo the four bolts (1).
2. Open the controller casing.
3. Remove the dummy plugs (2).



4. Use the cable support sleeve to guide the connection cable for the legionella protection pump or the bypass diverter valve through the opening in the controller casing.



Note

For simpler handling, you can completely remove the display by removing the plugs from the X1 (3) and eBUS (5) bushes. Suitable measures must be taken to prevent electrostatic discharging (ESD).


5. Insert the plug for the connection cable into bush X7 (6) in the solar controller.
6. If necessary, insert the display plug into the X1 bush (3).
7. If required, insert the eBUS plug into the eBUS bush (5).
8. If required, insert the connection cable plug for the heat requirement to the boiler into bush C1/C2 (4).
– The heat requirement is set via the T7 sensor.
9. Close the controller casing.
10. Tighten the bolts (1).
11. Secure the connection cable. Make sure that the connection cable is not routed directly next to the pipes through which the solar fluid flows.
12. On start-up, set the system components used in Multi-function output (→ Page 17).

5.8.2 Connecting the collector temperature sensor, cylinder temperature sensor and system controller

Preliminary work

1. Remove the front casing. (→ Page 10)
2. Open the narrow catch below the fault clearance button on the solar controller.
3. Install the collector temperature sensor in the last collector through which the fluid flows or, in the case of partial shading, in an unshaded collector.

Conditions: Bivalent cylinder with C1/C2 connection cable



- Install the cylinder temperature sensor (optional) in the cylinder dry pocket.
- Route the supply lines for the collector temperature sensor and the cylinder temperature sensor (optional) through the cable duct.

6 Start-up

- ▶ Route the supply line of the collector temperature sensor through one of the strain reliefs (4).
- ▶ Connect the supply line of the collector temperature sensor to the terminals (2).
- ▶ Route the supply line for the cylinder temperature sensor (optional) through one of the strain reliefs (4).
- ▶ Connect the supply line for the cylinder temperature sensor (optional) to the terminals (3).

Conditions: Bivalent cylinder with eBUS line

- ▶ Connect the cylinder temperature sensor to the boiler.
- ▶ Route the supply lines for the collector temperature sensor and the eBUS line for the system controller through the cable duct.
- ▶ Route the supply line of the collector temperature sensor through one of the strain reliefs (4).
- ▶ Connect the supply line of the collector temperature sensor to the terminals (2).
- ▶ Route the eBUS line of the system controller through one of the strain reliefs (4).
- ▶ Connect the eBUS line of the system controller to the terminals (1).

Conditions: Monovalent cylinder with bypass valve

- ▶ Install the cylinder temperature sensor on the hot water flow.
- ▶ Route the supply lines for the collector temperature sensor and the cylinder temperature sensor through the cable duct.
- ▶ Route the supply line of the collector temperature sensor through one of the strain reliefs (4).
- ▶ Connect the supply line of the collector temperature sensor to the terminals (2).
- ▶ Route the supply line of the cylinder temperature sensor through one of the strain reliefs (4).
- ▶ Connect the supply line of the cylinder temperature sensor to the terminals (3).

5.8.3 Routing the mains connection line



Caution.

Risk of damage caused by an incorrect connected voltage.


- ▶ Ensure that the rated voltage of the mains is 220-240 V.



Note

If pulsed residual currents as a result of short-term mains over-voltages and uneven phase loading occur during start-up procedures, we recommend pulse current sensitive RCDs (type A) or universal RCDs (type B) with short-time delay (VSK).

1. Use the power supply cable provided with the product to connect it to a fixed connection and an all-pole partition with a contact opening of at least 3 mm (e.g. fuses or power switches).



2. Note that the temperature limiter that is mounted on the cylinder is directly integrated into the mains connection line's phase. You should therefore disconnect the product from the power supply and connect the product's connection plug to the connection plug on the temperature limiter that is pre-installed at the factory. Otherwise, the product is not sufficiently connected to the power mains.
3. When establishing the plug connection, ensure that the outer push-on wings on the female connector reach into the connector tags on the male plug.

5.9 Completing installation

5.9.1 Checking the electrical installation

- ▶ Once the electrical installation is complete, ensure that all of the connections that have been established are firmly seated and are sufficiently insulated.

5.9.2 Installing the front casing

1. Fit the front casing from the front up to the stop.
2. Make sure that no cables are pinched or in contact with hot components and that the solar control is locked in place in the opening.
3. Secure the front casing with the bolt.
4. Fit the panel.

6 Start-up

To start up the product, you must fill the cylinder, the solar circuit and, if required, the heating circuit, check the system for leaks, complete the installation assistant and, if necessary, make any settings on other system components (e.g. on the system controller).

6.1 Checking and treating the heating water/filling and supplementary water



Caution.

Risk of material damage due to poor-quality heating water

- Ensure that the heating water is of sufficient quality.

- Before filling or topping up the system, check the quality of the heating water.

Checking the quality of the heating water

- Remove a little water from the heating circuit.
- Check the appearance of the heating water.
- If you ascertain that it contains sedimentary materials, you must desludge the system.
- Use a magnetic rod to check whether it contains magnetite (iron oxide).
- If you ascertain that it contains magnetite, clean the system and apply suitable corrosion-protection measures, or fit a magnet filter.
- Check the pH value of the removed water at 25 °C.
- If the value is below 6.5 or above 8.5, clean the system and treat the heating water.
- Ensure that oxygen cannot get into the heating water.

Checking the filling and supplementary water

- Before filling the system, measure the hardness of the filling and supplementary water.

Treating the filling and supplementary water

- Observe all applicable national regulations and technical standards when treating the filling and supplementary water.

Provided the national regulations and technical standards do not stipulate more stringent requirements, the following applies:

You must treat the heating water in the following cases:

- If the entire filling and supplementary water quantity during the operating life of the system exceeds three times the nominal volume of the heating installation, or
- If the guideline values listed in the following table are not met, or
- if the pH value of the heating water is less than 6.5 or more than 8.5.

Total heating output	Water hardness at specific system volume ¹⁾					
	≤ 20 l/kW		> 20 l/kW ≤ 50 l/kW		> 50 l/kW	
kW	°dH	mol/m³	°dH	mol/m³	°dH	mol/m³
< 50	< 16.8	< 3	11.2	2	0.11	0.02
> 50 to ≤ 200	11.2	2	8.4	1.5	0.11	0.02
> 200 to ≤ 600	8.4	1.5	0.11	0.02	0.11	0.02
> 600	0.11	0.02	0.11	0.02	0.11	0.02

1) Nominal capacity in litres/heating output; in the case of multi-boiler systems, the smallest single heating output is to be used.



Caution.

The use of unsuitable heating water may cause aluminium corrosion and a resulting lack of leak-tightness.

In contrast to steel, grey cast iron or copper, for example, aluminium reacts with alkaline heating water (pH value > 8.5) to produce substantial corrosion.

- When using aluminium, make sure that the pH value of the heating water is between 6.5 and a maximum of 8.5.



Caution.

Risk of material damage if the heating water is treated with unsuitable additives.

Unsuitable additives may cause changes in the components, noises in heating mode and possibly subsequent damage.

- Do not use any unsuitable frost and corrosion protection agents, biocides or sealants.

No incompatibility with our products has been detected to date with proper use of the following additives.

- When using additives, follow the manufacturer's instructions without exception.

We accept no liability for the compatibility of any additive or its effectiveness in the rest of the heating system.

Additives for cleaning measures (subsequent flushing required)

- Fernox F3
- Sentinel X 300
- Sentinel X 400

Additives intended to remain permanently in the system

- Fernox F1
- Fernox F2
- Sentinel X 100
- Sentinel X 200

Additives for frost protection intended to remain permanently in the system

- Fernox Antifreeze Alphi 11
- Sentinel X 500

- If you have used the above-mentioned additives, inform the operator about the measures that are required.
- Inform the operator about the measures required for frost protection.

6 Start-up

6.2 Filling and purging the system

1. Disconnect the product by removing the power supply to it using an all-pole partition with a contact opening of at least 3 mm (e.g. fuses or power switches).
2. Remove the front casing. (→ Page 10)

6.2.1 Opening the isolator devices

- Open all available isolator devices (on-site).

6.2.2 Filling and purging the cylinder

1. Make absolutely sure that the drain valve on the cylinder is closed.
2. Open the isolator device in the cold water pipe.
3. Open a hot water draw-off point and allow the air from the line to escape until the water comes out without any air bubbles.

6.2.3 Filling the heating circuit

- Fill the heating circuit via the filling and draining connection, → Installation and maintenance instructions for the boiler.

6.2.4 Filling and purging the solar system



Danger!

Risk of scalding from hot escaping solar fluid

When filling the solar circuit, hot solar fluid may escape and scald.

- Only fill the solar circuit when the collectors are cold.
- If the weather is sunny, fill the solar circuit at the beginning or end of the day or with the collectors covered.



Caution.

Malfunction caused by incorrectly rinsing and draining the collector rows

As a result of incorrectly rinsing and draining parallel interconnected collector rows, air may remain in the solar system.

- Provide each collector row with a stop valve.
- Rinse just one collector row at a time.
- After you have rinsed and drained all rows, open all of the stop valves.

1. Only fill the solar circuit with Vaillant ready-mixed solar fluid.
2. Fill the solar circuit using the Vaillant mobile filling device or the Vaillant filling pump.

6.2.4.1 Filling the solar system




Caution.

Malfunction caused by air in the solar circuit

As a result of incorrect filling, air may remain in the solar system.


- Supervise the filling of the solar system.

1. For larger solar systems, ensure that the solar circuit always contains enough solar fluid. If required, use additional containers.
2. Adjust the pre-charge pressure of the solar expansion vessel before filling the system.
3. Ensure that the filling pump is switched off.



4. Connect the filling device to the product as shown.
5. Open filling cocks (1) and (2) fully.
6. Switch the filling pump on.
7. Allow the filling pump to run for at least 15 minutes.
8. Keep an eye on the solar fluid level in the solar fluid container.
9. Ensure that the solar fluid container always contains enough solar fluid.
10. Check that the solar fluid is flowing back from the return hose into the solar fluid container.
 - ◁ If solar fluid escapes from the return hose without bubbles, the solar system is full.
11. Close the filling and drainage taps.
12. Switch the filling pump off.

6.2.4.2 Purging the solar system



1. Open the air vent screw (1) until solar fluid drips out.
 2. Close the air vent bolt.
- ◀ The system is filled and purged.

6.3 Running through the installation assistant

When the power supply to the product is switched on for the first time, the installation assistant is activated. It provides easy access to the most important check programmes and configuration settings for installing the product. The installation assistant is displayed whenever the product is switched on until it has been successfully completed.

The start of the installation assistant must be confirmed. Following confirmation, the product blocks all heat requirements. This status remains until the installation assistant is completed or cancelled.

If you do not confirm the launch of the installation assistant, it is closed 15 minutes after you switch on the unit and the basic display then appears. The next time the product is started, the installation assistant starts again.

- ▶ Switch on the power supply to the product.

6.3.1 Setting the language

1. Set the desired language using or .
2. Press to confirm the set language.
3. Press again to confirm the set language a second time and to prevent it being changed unintentionally.

6.3.2 Setting the date



Note

If a system controller has been connected, the date can be set on the system controller.

1. Use or to set the required year.
2. Use to confirm the set year.
3. Use or to set the required month.
4. Use to confirm the set month.
5. Use or to set the required day.
6. Use to confirm the set day.

6.3.3 Setting the time



Note

If a system controller has been connected, the time can only be set on the system controller.

1. Set the desired hour using or .
2. Confirm the set hour by pressing .
3. Set the desired minute using or .
4. Confirm the set minute by pressing .

6.3.4 Setting the electrical heating rod

1. Use or to set whether an electrical heating rod is present.
 2. Press to confirm this setting.
- ◀ You can use the **Water temperature** menu to deactivate the electrical heating rod (→ Page 18).



Note

If an electrical heating rod has been installed, it must be set in the menu.

6.3.5 Setting the number of collectors



Note

The product calculates the bars in the basic display depending on the number of collectors that are connected.

1. Use or to set the number of collectors.
2. Press to confirm this setting.

6.3.6 Setting the multi-function output

1. Use or to select the multi-function output function.
 - Not connect. (default setting): Multi-function output is switched off
 - LEG: Select this function when using a Legionella protection pump. The Legionella protection pump is actuated by the solar module when the Legionella programme is active.
 - BYP: Select this function to prevent excessive temperatures getting into the boiler. The T7 sensor must be available for this and a valve must be connected to the bypass outlet. The valve is switched when the measured value at the T7 sensor exceeds a preset limit value.
2. Press to confirm this setting.

6.3.7 Carrying out the purging programme

Menu → Installer level → Test menu → Check programmes → Purging programme

- ▶ Start the purging programme.
- ▶ Check in the sight glass above the pump whether the non-return flap is raised and the seal is visible.
 - ◀ If the seal is not visible, there is no volume flow.
- ▶ If there is no volume flow, you must purge the solar circuit with the filling device again.

6 Start-up

6.3.8 Setting contact data

1. Press , , and to set your telephone number.
2. Confirm this change by pressing .

6.3.9 Completing the installation assistant

- To complete the installation assistant, press .



Note

Once the installation assistant has been completed and confirmed, it will not start up automatically next time the unit is switched on.



Note

All the settings that have been made can be viewed and changed subsequently under the menu point **Configuration**.

6.4 Test menu

As well as the installation assistants, you can also call up the test menu for start-up, maintenance and troubleshooting.

Menu → Installer level → Test menu

This contains **Statistics**, **Check programmes** and the **Sensor/actuator test**.

6.4.1 Statistics

Menu → Installer level → Test menu → Statistics

This displays the operating hours for:

- Solar pump

6.4.2 Check programmes

Menu → Installer level → Test menu → Check programmes

The following check programmes are available:

- Start purging programme

6.4.3 Sensor/ actuator test

Menu → Installer level → Test menu → Sensor/actuator test

The current values of the following sensors can be read off here:

- T1 temperature sensor
- T5 collector temperature sensor
- T7 cylinder temperature sensor (if present)
- Solar pump
- LEG/BYP
- 3-way valve
- Solar circuit flow rate

The selection button can be used to activate the following actuators. You can then use the plus and minus buttons to change the output of the pumps or the flow direction of the valve.

In addition, you can view the **Solar circuit flow rate**. The value is calculated from the pump output and rotational speed.

6.5 Configuration

You can use the menu **Configuration** to subsequently change the settings that have been made using the installation assistant.



Note

To prevent damage to the electric heater, you cannot activate the electric heater separately – it can only be started via a test programme.

- Language
- Contact data
- Date
- Time
- Summer/winter time
- Number of collectors
- Electric heater available
- Multi-function output

In addition, the following information can be set or read:

- Operating mode
- Hot water set target temperature
- Maximum cylinder temperature
- Switch-on diff.
- eBUS control
- 4 x time periods (Monday-Friday 1, Monday-Friday 2, Saturday-Sunday 1, Saturday-Sunday 2)
- Anti-legionella function
- Switching temperature for multi-function output (only shown if the multi-function relay is set to BYP)
- Starting differential temperature for solar charging
- Stop differential temperature for solar charging
- Start temperature for frost protection
- Stop temperature for frost protection
- Software version

6.5.1 Time periods

Menu → Installer level Configuration

- **Sun:** Recharging function is always ready
- **Moon:** No recharging

6.5.2 Hot water set target temperature



Note

If cylinder temperature sensor T7 is installed or an electrical heating rod is activated, then this menu point can be set up.

Menu → Installer level → Configuration → Water temperature

The set target temperature for hot water is factory-set to 60 °C. You can set values between 20 °C and 70 °C.

The set target temperature applies to the electrical heating rod and to a post-heating installation (on C1/C2).

6.5.3 Maximum cylinder temperature

Menu → Installer level → Configuration → Max. cylinder temp.



Note

A high cylinder temperature influences the calcification of the cylinder. Therefore, if there is a high limescale content in the water, reduce the value for the maximum cylinder temperature.

The maximum cylinder temperature is set in the factory at 85 °C. You can set values between 60 °C and 85 °C.

If the temperature measured at T1 and T6 is less than the maximum cylinder temperature by at least 10 °C, solar charging starts.

6.5.4 Anti-legionella function

Menu → Installer level → Configuration → Anti-legionella funct.

You can set the anti-legionella function:

- Daily (every 24 h)
- Weekly (every 168 h)

If the hot water temperature in the cylinder exceeded 70 °C during the set interval, the interval is restarted.

The anti-legionella function is only carried out if the hot water temperature did not reach 70 °C within the interval.

6.5.5 Switch-on diff.

Menu → Installer level → Configuration → Switch-on diff

This is where the temperature difference that is required between the T6 cylinder temperature sensor and the collector temperature sensor is set, to ensure that the solar pump is started.

6.5.6 Solar switch-off diff.

Menu → Installer level → Configuration → Solar switch-off diff.

This is where the temperature difference that is required between the T1 cylinder temperature sensor and the T6 cylinder temperature sensor is set to ensure that the solar pump stops.

6.5.7 Hot water switch-on diff.

Menu → Installer level → Configuration → Hot water switch-on diff.

This is where the temperature difference that is required between the hot water target value and the T6 cylinder temperature sensor is set to ensure that electrical recharging starts.

6.5.8 Min. pump PWM

Menu → Installer level → Configuration → Min. pump PWM

This is the smallest possible value to which the solar pump can be adjusted in solar mode.

6.5.9 eBUS control

Menu → Installer level → Configuration → eBUS control

This shows whether the solar control recognises the system controller.

6.5.10 Software version

Menu → Installer level → Configuration → Software version

This shows the current software version that is installed on the solar control. The software versions of the display (AI) and the main PCB (SMU) are shown alternately.

6.6 Documenting start-up

- The following settings and values should be documented in the hand-over check-list for the operator:
 - System parameters
 - System flushing and filling
 - Installation tests
 - Controller settings

7 Handing over to the operator

1. Inform the operator of the solar system about the handling and function of the product.
2. Explain the general safety information to the operator.
3. Draw special attention to the safety instructions which the operator must follow.
4. Explain to the operator the function and location of safety devices on the system.
5. Tell the operator how often they need to activate the safety device (depending on water hardness).
6. Explain the importance of regular maintenance by a competent heating specialist company to the operator. To ensure that maintenance work is carried out on a regular basis, we recommend signing up to a maintenance contract.
7. Hand the product over to the operator.
8. Explain the basic operation of the product to the operator.
9. Provide the operator with all relevant instructions and product documentation for safe-keeping.
10. Go through the operating instructions with the operator.
11. Answer any questions they may have.
12. Make the operator aware of the need to keep the instructions near the product, but not in or on the product.
13. Explain to the operator which measures are required to top up and purge the heating installation if required.
14. Explain to the operator how to correctly set the temperatures, the controllers and the thermostatic radiator valves (economically).
15. Inform the operator of the pump conditions.
16. Explain the guarantee conditions to the operator.

8 Rectifying faults

8 Rectifying faults

8.1 Detecting and rectifying faults

You can find an overview of the faults, possible causes and remedies in the appendix.

Detecting and rectifying faults (→ Page 25)

8.1.1 Querying the fault memory

Menu → Installer level Fault list

The product has a fault memory. You can use this to query the last ten faults that occurred in chronological order.

- To switch between the faults that are present, press  or .
- To delete the entire fault memory, press  ("Delete").

8.1.2 Overview of the fault codes



Note

Only a competent person can eliminate the cause of the faults described below and delete the fault memory.

Fault code	Fault text
1069	T7 cylinder temperature sensor fault
1070	Coding resistor missing
1273	Electronics fault in solar pump
1276	Solar pump blocked
1278	T5 collector sensor fault
1279	T6 temperature sensor fault
1281	T1 temperature sensor fault
M.45	Solar pump dry run

8.2 Restarting the solar pump

- If the solar pump has a fault, restart the solar pump by pressing the reset button on the solar pump.

9 Inspection and maintenance

9.1 Inspection and maintenance check-list

The following table shows the inspection and maintenance work that must be carried out at specific intervals.

Inspection and maintenance work	Interval
Solar circuit	
Check solar fluid	Annually
Check solar pump function	Annually
Check fluid level in solar circuit, top up as required	Annually
Collectors	
Visual inspection of the collectors, collector fastenings and connections	Annually
Check that the retainers and collector components are clean and fitted properly	Annually
Check the pipe insulations for damage	Annually

Inspection and maintenance work	Interval
Solar controller	
Check the pump function	Annually
Check the sensor temperature display	Annually
Check the solar yield for plausibility	Annually
Cylinder	
Servicing the magnesium protection anode	Annually
Cleaning the inner vessel	Annually
Check the connections for leaks	Annually
Heating circuit	
Checking the settings for the time scheduling/timer programmes	Annually
Checking the functions of the thermostatic mixer	Annually

9.2 Observing inspection and maintenance intervals



Danger!

Risk of damage and personal injury as a result of neglected and improper inspection and maintenance.

Inspection and maintenance must only be performed by a competent person.

- Carry out the inspection and maintenance work described on a regular basis and to a professional standard.

Regular inspection/maintenance and exclusive use of original spare parts are absolutely essential to ensure fault-free operation and a long working life for the product.

We recommend taking out an inspection or maintenance agreement.

9.3 Procuring spare parts

The original components of the product were also certified by the manufacturer as part of the declaration of conformity. If you use other, non-certified or unauthorised parts during maintenance or repair work, this may void the conformity of the product and it will therefore no longer comply with the applicable standards.

We strongly recommend that you use original spare parts from the manufacturer as this guarantees fault-free and safe operation of the product. To receive information about the available original spare parts, contact the contact address provided on the reverse of these instructions.

- If you require spare parts for maintenance or repair work, use only the spare parts that are permitted for the product.

9.4 Preparing inspection and maintenance work



Danger! **Risk of death from electric shock!**

A continuous voltage is always present on the mains connection terminals L and N.

- Before starting work, disconnect the product from the power mains by de-energising the product using an all-pole partition with a contact opening of at least 3 mm (e.g. fuses or power switches).

- Remove the front casing. (→ Page 10)

9.5 Replacing the mains connection line

1. Check the mains connection line for damage.
2. Replace the mains connection line if it is defective.
3. To do this, contact customer service.

9.6 Checking and replacing solar fluid



Caution. **Risk of damage due to old solar fluid.**

As a result of ageing, solar fluid may lose its frost- and corrosion-protection properties.

- Check the solar fluid annually.
- Replace the solar fluid if necessary.



Caution. **Risk of damage due to unsuitable solar fluid.**

The use of unsuitable solar fluid may cause malfunctions and damage to the solar system.

- Use only Vaillant solar fluid.

1. If an inspection shows that the solar fluid has lost its frost- and corrosion-protection properties, replace the solar fluid.
2. To completely drain the solar circuit, blow through it with compressed air. Then completely fill the solar circuit.


9.6.1 Check solar fluid

1. Check the solar fluid using an antifreeze tester or a refractometer.
2. While the system is in standby, use a silicone tube to check the filling level at the purging valve.

9.6.2 Draining the solar fluid

Preliminary work

- Switch off the solar system by interrupting the power supply.



1. Connect a hose that runs down to the floor from the purging valve (1).
2. Place the end of the hose in a collecting container that is suitable for storing solar fluid (2) and which has sufficient capacity (20 l or 40 l capacity). Hold the hose in the collecting container in such a way that air can flow into it.
3. To ensure that you are sufficiently protected against escaping hot vapour and solar fluid, do not immerse the end of the hose in the solar fluid.
4. Open the purging valve.
 - ◀ Beware of hot solar fluid or vapour being emitted.
5. Connect a hose that runs down to the floor to the fill and drain connection (3).
6. Place the end of the hose in the collecting container (2) as well.
7. Make sure that the hose on the purging valve is not hanging in the solar fluid and that air can be sucked up into it.
8. Open the valve on the fill and drain connection.
9. Completely drain the solar fluid.
10. Close the valve on the fill and drain connection.
11. Remove the hose from the fill and drain connection.


9.6.3 Adding solar fluid

- Fill and purge the solar system. (→ Page 16)

9 Inspection and maintenance


9.7 Checking the magnesium protection anode and cleaning the cylinder's inner vessel

9.7.1 Checking the magnesium protection anode



1. Remove the cover (1) from the magnesium protection anode (2).
2. Unscrew the magnesium protection anode.
3. Check the magnesium protection anode for wear.
4. Check and, if required, replace the seals.
5. If required, replace the magnesium protection anode.
6. Screw the magnesium protection anode back in.
7. Check that the cylinder is leak-tight.

9.7.2 Draining the product



1. Switch off the product. (→ Page 23)

2. Close the isolator device in the product's cold water pipe.
3. Secure a suitable hose to the drain valve (1).
4. Place the free end of the hose in a suitable outflow location.
5. Open the drain valve.
6. Open the highest hot water draw-off point to ventilate and drain the water pipes completely.
7. Once the water has completely drained out, close the drain valve and the hot water draw-off point again.
8. Remove the hose from the drain valve.

9.7.3 Cleaning the inner vessel

1. In the inner vessel, clean away any remaining dirt through the opening for the magnesium protection anode.
2. Tighten the magnesium protection anode.
3. Fill and purge the cylinder. (→ Page 16)
4. Check that the cylinder is leak-tight.

9.8 Checking the expansion relief valve

1. Check that the expansion relief valve works correctly by venting it.
2. If, when venting, no water escapes or if the expansion relief valve does not close tight, replace the expansion relief valve.

9.9 Checking and replacing the electrical heating rod

1. Check that the electrical heating rod is working correctly.
 - **Menu → Installer level → Test menu → Check programmes → Test electrical heating rod**



Note

The check programme checks whether the solar pump generates a volume flow and, after the electrical heating rod starts up, checks whether the temperature increases.

2. Replace the electrical heating rod if it is defective.
3. To do this, observe the assembly instructions that are enclosed with the new electrical heating rod.

9.10 Additional tests/tasks

We recommend that the solar plant be serviced at the same time as the complete heating installation.

- ▶ Check the collectors and collector fastenings for dirt and to ensure that they are securely fitted.
- ▶ Check that the displayed values are plausible for the solar yield.
- ▶ Instruct the operator to test the pump's blockage prevention function every 24 hours to ensure that it works without any faults.

9.11 Completing inspection and maintenance work

Once you have completed all maintenance work:

- ▶ Check to ensure that the electrical wiring is connected properly.
- ▶ Open the service valves.
- ▶ Switch the power supply on again.
- ▶ Check the product to ensure that no solar fluid, heating water or hot water is leaking.
- ▶ Install the front casing. (→ Page 14)
- ▶ Ensure that the basic display is shown and that no fault message is displayed.
- ▶ While the time period is activated, ensure that the correct symbol (sun or moon) is shown in the display.
- ▶ If you have replaced or topped up the solar fluid, use the **T.05** sensor/actuator test to start the solar pump and look in the viewing window to check whether a volume flow occurs.
- ▶ If you have installed an electrical heating rod, use check programme **P.02** to test this.
- ▶ Carry out a test operation run.

10 Decommissioning

10.1 Temporary decommissioning

10.1.1 Switching off the product

- ▶ Use the partition that is installed on-site (e.g. fuses or power switches) to disconnect the product from the power supply.

10.1.2 Ensuring that frost protection is provided

- ▶ Drain the product. (→ Page 22)

10.1.3 Closing isolator devices

- ▶ Also close all of the isolator devices that are available on-site.

10.2 Permanently decommissioning

10.2.1 Switching off the product

- ▶ Use the partition that is installed on-site (e.g. fuses or power switches) to disconnect the product from the power supply.

10.2.2 Completely draining the cylinder, solar and heating installation

1. Drain the product. (→ Page 22)
2. Drain the solar fluid. (→ Page 21)
3. Completely drain the heating circuit.
4. Ensure that the solar fluid is disposed of correctly (Disposing of solar fluid (→ Page 23)).

11 Recycling and disposal

11.1 Recycling and disposal

Disposing of the packaging

- ▶ Dispose of the packaging correctly.
- ▶ Observe all relevant regulations.

11.2 Disposing of solar fluid

- ▶ Ensure that the solar fluid is disposed of at an appropriate waste site or waste incineration plant, for example, in compliance with local regulations.
- ▶ Contact the local municipal sanitation department or the mobile environmental service for quantities under 100 l.

12 Customer service

Applicability: EXP English-speaking, Vaillant

For contact details for our customer service department, you can write to the address that is provided on the back page, or you can visit www.vaillant.com.

Appendix

Appendix

A Installer level – Overview

Setting level	Values		Unit	Increment, select, explanation	Default setting
	Min.	Max.			
Installer level →					
Enter code	00	99	–	1 (competent person code 17)	–
Installer level → List of faults →					
F.XX - F.XX ¹	Current value		–	–	–
Installer level → Test menu → Statistics →					
Solar pump	Operating hours		h		–
Installer level → Test menu → Check programmes →					
P.01 Start purge programme	–	–	–	Yes, No	–
P.02 Test electrical heating rod	–	–	–	Yes, No	–
Installer level → Test menu → Sensor/actuator test →					
T.01 T1 temperature sensor	–	–	°C		–
T.02 T5 collector sensor	–	–	°C		–
T.03 T6 cylinder sensor	–	–	°C		–
T.04 T7 cylinder sensor	–	–	°C		–
T.05 Solar pump	0	100	%	5; off, 0, 100	–
T.07 LEG/BYP valve	–	–	–	On, Off	–
T.08 3-way valve electrical heating rod	–	–	–	On, Off	–
T.10 Solar circuit flow rate	–	–	l/min		–
Installer level → Configuration →					
Target hot water temperature	Off, 20	70	°C	1 Product with hot water generation	60
Max. cylinder temp.	60	85	°C	–	85
Mo-Fr, 1st time per.	00:00	00:00	–	10 minutes This is displayed if an electrical heating rod or the T7 cylinder sensor is connected.	06:00–22:00
Mo-Fr, 2nd time per.	00:00	00:00	–	10 minutes This is displayed if an electrical heating rod or the T7 cylinder sensor is connected.	24:00–24:00
Sa-Su, 1st time per.	00:00	00:00	–	10 minutes This is displayed if an electrical heating rod or the T7 cylinder sensor is connected.	06:00–22:00
Sa-Su, 2nd time per.	00:00	00:00	–	10 minutes This is displayed if an electrical heating rod or the T7 cylinder sensor is connected.	24:00–24:00
Legionella protect.	–	–	–	Daily, Weekly, Off	Off
Date	–	–	–	Current date	–
Daylight saving time	Automatic clock change		–	On, Off	Off
Number of collectors	1	3	–	–	3
Electrical heating rod	–	–	–	yes, no	no
Multi-function output	–	–	–	Not connected, Legionella protection pump, Bypass	Not connected
¹ Fault lists are only displayed, and can only be deleted, if faults have occurred.					

Setting level	Values		Unit	Increment, select, explanation	Default setting
	Min.	Max.			
Bypass switch. temp.	20	65	°C	1; the valve is moved at this temperature.	50
Solar switch-on diff.	6	20	°C	1; difference between T5 and T6	12
Switch-off diff.	1	5	°C	1; difference between T1 and T6	3
DHW switch-on diff.	5	25	°C	1; difference between hot water temperature target value and T6	15
Min. pump PWM	10	100	%	1; smallest volume required to actuate the pump	15
Frost prot. start temp.	0	12	°C	1	10
Frost prot. stop temp.	14	20	°C	1	15
eBUS controller	–	–	–	Recognised, not recognised	–
Software version	–	–	–	Displaying the software version	–
Language	–	–	–	Deutsch, English, Français, Italiano, Dansk, Nederlands, Castellano, Türkce, Magyar, Русский, Українська, Svenska, Norsk, Polski, Čeština, Hrvatski, Slovenčina, Română, Slovenščina, Português, Srpski	English
Contact data	Phone number		–	0-9	–
Installer level → Resets →					
Factory settings	–	–	–	Yes, No Restore the default settings?	–
Solar yield	–	–	–	Yes, No Reset the solar yield display?	–
Installer level → Start inst. assistant →					
Language	–	–	–	Deutsch, English, Français, Italiano, Dansk, Nederlands, Castellano, Türkce, Magyar, Русский, Українська, Svenska, Norsk, Polski, Čeština, Hrvatski, Slovenčina, Română, Slovenščina, Português, Srpski	English
Date	–	–	–	Current date	–
Time	–	–	–	Current time	–
Daylight saving time	Automatic clock change		–	On, Off	Off
Electrical heating rod	–	–	–	yes, no	no
Number of collectors	1	3	–	–	3
Multi-function output	–	–	–	Not connected, Legionella protection pump, Bypass	Not connected
Check programmes	–	–	–	Starts automatically	–
End the installation assistant?	–	–	–	Yes, No	–
¹Fault lists are only displayed, and can only be deleted, if faults have occurred.					


B Detecting and rectifying faults

Fault	Possible cause	Explanation/remedy
The pumps start up at irregular intervals, including at night	Blockage prevention function	No fault
The collectors are colder than the cylinder, the solar system starts	The collectors are colder than the top cylinder (temperature can be seen on the screen), but warmer than the bottom cylinder	No fault
Solar yield unusually high	High heat losses	Insulate the system The solar yield is always higher than the primary energy that is saved
System or product are making noises	Gurgling noise when starting up/stopping is normal	No fault

Appendix

Fault	Possible cause	Explanation/remedy
System or product are making noises	Air in the solar pump	Purge the solar pump
Displayed temperature is incorrect	Poor connection of the temperature sensor	Check the seating and position of the temperature sensor
The solar fluid level falls over time	Solar circuit leaking	Find and seal any leaks
	Pressure too high and expansion relief valve discharges	Check the expansion relief valve function
Solar pump running, solar fluid is not being pumped	Stop valve closed	Open the stop valve
	Pressure losses too high	Check the solar circuit function
	Air in the solar circuit	Rinsing the system again
Some setting parameters cannot be changed (time, date, etc.)	Product was/is connected to a system controller	Remove the system controller and restart the product (press the fault clearance key)
Noise when starting the solar charging system with electrical heating rod for the first time	Air in the system	Start the reset process and wait for it to start a second time

C Connection diagram



- | | | | |
|---|-----------------------------------|---|---|
| 1 | Solar charger | 6 | Legionella protection pump or hot water valve to protect the boiler |
| 2 | Safety overheat cut-off device | 7 | 3-way valve for electrical heating rod |
| 3 | Electrical heating rod | 8 | 230 V control signal for electrical heating rod |
| 4 | Solar pump 1 | 9 | eBUS connection |
| 5 | VMS 8 D only: Optional solar pump | | Internal extension. Use the connection underneath the display. |

10	Collector temperature sensor Internal extension. Use the connection underneath the display.	12	Connection for the C1/C2 connection cable to the heat generator You must only connect extra-low voltage of ≤ 24 V with a maximum amperage of 200 mA at this connection.
11	Top cylinder temperature sensor Internal extension. Use the connection underneath the display.		

D Technical data

Technical data – Cylinder

	VIH S1 250/4 B	VIH S2 250/4 B	VIH S1 350/4 B	VIH S2 350/4 B
Cylinder volume	250 l	250 l	350 l	350 l
Volume of solar fluid (incl. solar pump unit and optional electrical heating rod)	≤ 10 l	≤ 10 l	≤ 12 l	≤ 12 l
Permissible solar circuit operating pressure	≤ 0.6 MPa	≤ 0.6 MPa	≤ 0.6 MPa	≤ 0.6 MPa
Permissible hot water operating pressure	≤ 1.0 MPa	≤ 1.0 MPa	≤ 1.0 MPa	≤ 1.0 MPa
Permissible heating circuit operating pressure	≤ 0.3 MPa	≤ 0.3 MPa	≤ 0.3 MPa	≤ 0.3 MPa
Solar flow temperature	≤ 130 °C	≤ 130 °C	≤ 130 °C	≤ 130 °C
Hot water temperature	≤ 99 °C	≤ 99 °C	≤ 99 °C	≤ 99 °C
Number of collectors	1 ... 2	1 ... 2	2 ... 3	2 ... 3

Technical data – Solar charging system

	VMS 8	VMS 8 with electrical heating rod
Electrical heating rod power		2.5 kW
Solar pump output	≤ 70 W	≤ 70 W
Operating voltage	220 ... 240 V _{AC}	220 ... 240 V _{AC}
Frequency	50 Hz	50 Hz
Level of protection	IPX1	IPX1
Integrated expansion relief valve for the solar circuit	0.6 MPa	0.6 MPa

E Maximum daily hot water output

Load type	Volume	Cylinder size 250 l (bi-valent cylinder)	Cylinder size 350 l (bi-valent cylinder)
		3-6 people	4-7 people
Hot water output in winter at 60 °C ($\Delta T = 35$ K)	Standard household N _L	2.0	2.5
Litres at $\Delta T = 35$ K (from 10 °C to 45 °C) with boiler and target hot water temperature = 60 °C	l/10 min.	195	215
Litres at $\Delta T = 35$ K (from 10 °C to 45 °C), solar mode only, at a maximum cylinder temperature of 85 °C	l/10 min.	448	601



0020206919_02 ■ 12.02.2016

Vaillant Group International GmbH

Berghauser Strasse 40 ■ 42859 Remscheid

Telefon 021 91 18-0

info@vaillant.de ■ www.vaillant.com

© These instructions, or parts thereof, are protected by copyright and may be reproduced or distributed only with the manufacturer's written consent.

We reserve the right to make technical changes.