

atmoMAG

MAG mini ...4/1 Z, MAG ...4/1 Z



Operating instructions

Contents

1	Safety	3
1.1	Action-related warnings	3
1.2	Intended use	3
1.3	General safety information	3
2	Notes on the documentation	5
2.1	Observing other applicable documents	5
2.2	Storing documents	5
2.3	Validity of the instructions	5
3	Product description.....	5
3.1	Information on the data plate	5
3.2	Control elements.....	5
3.3	CE marking	5
4	Operation.....	5
4.1	Cabinet-type casing	6
4.2	Preparing for start-up.....	6
4.3	Starting up the product	6
4.4	Switching on the product	6
4.5	Drawing hot water.....	6
4.6	Setting the domestic hot water temperature.....	6
4.7	Modulation	7
5	Troubleshooting	7
5.1	Detecting and eliminating faults.....	7
5.2	Eliminating faults in the product.....	7
6	Care and maintenance	7
6.1	Maintenance	7
6.2	Caring for the product	7
7	Decommissioning.....	7
7.1	Temporarily decommissioning the product.....	7
7.2	Having the product permanently decommissioned.....	7
7.3	What to do if there is a risk of frost	7
8	Recycling and disposal.....	8

1 Safety

1.1 Action-related warnings

Classification of action-related warnings

The action-related warnings are classified in accordance with the severity of the possible danger using the following warning symbols and signal words:

Warning symbols and signal words



Danger!

Imminent danger to life or risk of severe personal injury



Danger!

Risk of death from electric shock



Warning.

Risk of minor personal injury



Caution.

Risk of material or environmental damage

1.2 Intended use

There is a risk of injury or death to the user or others, or of damage to the product and other property in the event of improper use or use for which it is not intended.

The products are gas-fired instantaneous water heaters and, as such, are intended for hot water generation.

Intended use includes the following:

- observance of the operating instructions included for the product and any other installation components
- compliance with all inspection and maintenance conditions listed in the instructions.

This product can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved. Children must not play with the product. Cleaning and user maintenance work must not be carried out by children unless they are supervised.

Any other use that is not specified in these instructions, or use beyond that specified in this document, shall be considered improper

use. Any direct commercial or industrial use is also deemed to be improper.

Caution.

Improper use of any kind is prohibited.

1.3 General safety information

1.3.1 Installation by competent persons only

The installation, inspection, maintenance and repair of the product, as well as the gas settings and gas conversions, must only be carried out by a competent person.

1.3.2 Danger caused by improper operation

Improper operation may present a danger to you and others, and cause material damage.

- ▶ Carefully read the enclosed instructions and all other applicable documents, particularly the "Safety" section and the warnings.
- ▶ Only carry out the activities for which instructions are provided in these operating instructions.

1.3.3 Risk of death from escaping gas

What to do if you smell gas in the building:

- ▶ Avoid rooms that smell of gas.
- ▶ If possible, open doors and windows fully and ensure adequate ventilation.
- ▶ Do not use naked flames (e.g. lighters, matches).
- ▶ Do not smoke.
- ▶ Do not use any electrical switches, mains plugs, doorbells, telephones or other communication systems in the building.
- ▶ Close the emergency control valve or the main isolator.
- ▶ If possible, close the gas stopcock on the product.
- ▶ Warn other occupants in the building by yelling or banging on doors or walls.
- ▶ Leave the building immediately and ensure that others do not enter the building.
- ▶ Alert the police and fire brigade as soon as you are outside the building.
- ▶ Use a telephone outside the building to inform the emergency service department of the gas supply company.



1.3.4 Risk of death due to blocked or leaking flue pipework

What to do if you smell flue gas in the property:

- ▶ Open all accessible doors and windows fully to provide ventilation.
- ▶ Switch off the product.
- ▶ Inform a competent person.

1.3.5 Risk of death due to explosive and flammable materials

- ▶ Do not use the product in storage rooms that contain explosive or flammable substances (such as petrol, paper or paint).

1.3.6 Risk of death due to changes to the product or the product environment

- ▶ Never remove, bridge or block the safety devices.
- ▶ Do not tamper with any of the safety devices.
- ▶ Do not damage or remove any tamper-proof seals on components.
- ▶ Do not make any changes:
 - The product itself
 - to the gas, supply air, water and electricity supply lines
 - to the entire flue system
 - to the expansion relief valve
 - to the drain pipework
 - to constructional conditions that may affect the operational reliability of the product

1.3.7 Risk of poisoning caused by insufficient combustion air supply

Condition: Open-flued operation

- ▶ Ensure that there is a sufficient combustion air supply.

1.3.8 Risk of corrosion damage due to unsuitable combustion and room air

Sprays, solvents, chlorinated cleaning agents, paint, adhesives, ammonia compounds, dust or similar substances may lead to corrosion on the product and in the air/flue pipe.

- ▶ Ensure that the combustion air supply is always free of fluorine, chlorine, sulphur, dust, etc.

- ▶ Ensure that no chemical substances are stored at the installation site.

1.3.9 Risk of injury and material damage due to maintenance and repairs carried out incorrectly or not carried out at all

- ▶ Never attempt to carry out maintenance work or repairs on your product yourself.
- ▶ Faults and damage should be immediately eliminated by a competent person.
- ▶ Adhere to the maintenance intervals specified.

1.3.10 Risk of burns or scalding caused by hot parts

Parts of the product become hot during operation.

- ▶ Only touch the product and its parts once these have cooled down.

1.3.11 Risk of death due to lack of safety devices

A lack of safety devices (e.g. expansion relief valve, expansion vessel) can lead to potentially fatal scalding and other injuries, e.g. due to explosions.

- ▶ Ask a competent person to explain how the safety devices work and where they are located.



2 Notes on the documentation

2.1 Observing other applicable documents

- Always observe all operating instructions enclosed with the installation components.

2.2 Storing documents

- Store these instructions and all other applicable documents for further use.

2.3 Validity of the instructions

These instructions apply only to:

Product article number

MAG mini 114/1 Z(P-INT)	0010022594
MAG 144/1 Z(P-INT)	0010022524


3 Product description

3.1 Information on the data plate

The data plate is mounted at the front of the down-draught diverter, under the product casing, at the factory.

Information on the data plate	Meaning
MAG	Product category
11/14	Power in l/min
-4/1	Chimney connection/product generation
Z	With Piezo ignition
atmoMAG	Product series
Type B11 BS	Approved gas-fired units
Cat II	Multiple gas type boiler
2H3P	Unit category
G20/31	Permitted gas types with connection pressures
P _{nom.}	Maximum heat output
P _{min.}	Minimum heat output
Q _{nom.}	Maximum heat input
Q _{min.}	Minimum heat input
P _{w max.}	Maximum permissible water pressure
Serial number	7th to 16th digit = product article number

3.2 Control elements



- | | | | |
|---|---|---|----------------------------|
| 1 | Flow rate selector/temperature selector | 3 | Piezo igniter |
| 2 | Rotary power switch (10-stage from 50-100%) | 4 | Control panel |
| | | 5 | Ignition flame sight glass |

3.3 CE marking



The CE marking shows that the products comply with the basic requirements of the applicable directives as stated on the declaration of conformity.

The declaration of conformity can be viewed at the manufacturer's site.

4 Operation



Warning.

Risk of being scalded by hot water.

Incorrectly set hot water temperatures and hot water in the lines may lead to scalding.

- Check the hot water temperature with your hand.



Warning.

Risk of burns caused by touching the sight glass!

- ▶ Avoid direct contact with the heat-conducting sight glass.



Caution.

Risk of material damage caused by an interrupted water supply.

- ▶ Ensure that the water supply cannot be interrupted.

4.1 Cabinet-type casing

Enclosing the product in cabinet-type casing requires compliance with the applicable design instructions.

If you require cabinet-type casing for your product, consult a heating specialist company. Never, under any circumstances, enclose the product yourself.


4.2 Preparing for start-up

1. Ask the competent person who installed the product to explain to you where these isolator devices are located and how to handle them.
2. Open the gas isolator cock fully.
3. Open the cold water stop valve that is set on-site.

4.3 Starting up the product

- ▶ Only start up the product once the casing has been completely closed.

4.4 Switching on the product



1. Turn the rotary power switch (1) clockwise to the ignition position (lightning symbol) and press it.
2. Press down and hold the rotary power switch in this position and actuate the Piezo igniter (2) by pressing it several times.
 - ◁ Each time the Piezo igniter is pressed, this creates one single ignition spark. The ignition flame is ignited.

3. While the ignition flame is burning, hold the rotary power switch in this position for another 10-15 seconds.
4. Observe the ignited ignition flame through the sight glass. If the product was shut down for an extended period, air may have accumulated in the ignition gas line. In this case, repeat the ignition procedure.



Note

If you notice leaks in the hot water pipes between the product and the draw-off points, you must immediately close the cold-water isolation valve that was set on-site. Have the leaks eliminated by a competent person.

4.5 Drawing hot water


1. Open the hot water valve at the draw-off point.
 - ◁ The product automatically starts up.

Condition: No hot water is supplied.

- ▶ Ensure that any stop valve that is installed upstream of the hot water valve is completely open.
- ▶ Ensure that the pilot flame has ignited.
- ▶ Remove the filter that is installed in the hot water valve and check the filter for dirt and limescale.
- ▶ Use a descaling solution to remove the limescale from the filter.

2. Close the hot water valve on the draw-off point.
 - ◁ The product automatically shuts down.

4.6 Setting the domestic hot water temperature



1. Turn the temperature selector (1) clockwise to decrease the domestic hot water flow rate.
 - The domestic hot water temperature is thereby affected (increased).
2. Turn the rotary power switch (2) anti-clockwise to increase the burner output.
 - The domestic hot water temperature is thereby increased.
3. Turn the temperature selector (1) anti-clockwise to increase the domestic hot water flow rate.

- The domestic hot water temperature is thereby affected (reduced).
4. Turn the rotary power switch **(2)** clockwise to decrease the burner output.
- The domestic hot water temperature is thereby reduced.



Note

If you increase the domestic hot water flow rate and turn the rotary power switch anti-clockwise, the gas consumption is increased.

4.7 Modulation

The burner output (gas flow rate) is continually and automatically matched to the domestic hot water flow rate in the range between the preselected setting on the rotary power switch and the product's lowest possible output (approx. 35%). As a result, the domestic hot water temperature is kept at a constant.

5 Troubleshooting

5.1 Detecting and eliminating faults

A fault is present if the product does not generate any hot water. As the end user, you may only proceed as follows:

- ▶ Use the sight glass to check whether the ignition flame is still burning.
- ▶ If the ignition flame goes out, switch the product on (→ Page 6).
- ▶ If the ignition flame repeatedly goes out or no hot water is generated, contact a competent person to eliminate the problem.

5.2 Eliminating faults in the product

- ▶ If the product was blocked by a safety device, wait approx. 10 minutes and then start up the product again.
- ▶ If the product is repeatedly blocked by a safety device or does not start up, contact a competent person to have the fault eliminated.
- ▶ Only start the product up again once the fault has been eliminated by a competent person.

6 Care and maintenance

6.1 Maintenance


An annual inspection and biennial maintenance of the product carried out by a competent person is a prerequisite for ensuring that the product is permanently ready and safe for operation, reliable, and has a long service life. The inspection may require maintenance to be carried out earlier, depending on the results.

6.2 Caring for the product

- ▶ Clean the casing with a damp cloth and a little solvent-free soap.
- ▶ Do not use sprays, scouring agents, detergents, solvents or cleaning agents that contain chlorine.

7 Decommissioning

7.1 Temporarily decommissioning the product




- ▶ Turn the power switch **(1)** clockwise from the position for "ready for operation" as far as it goes.
- ▶ Close the gas isolator cock that was set on-site.
 - ◁ The gas supply to the burner on the gas-fired instantaneous water heater is now blocked.
- ▶ Close the cold water stop valve that is set on-site.

7.2 Having the product permanently decommissioned

- ▶ Have a competent person permanently decommission the product.

7.3 What to do if there is a risk of frost



If there is a risk of frost, it is necessary to protect the product against freezing. To do this, you must drain your gas-fired instantaneous water heater.

- ▶ Temporarily decommission (→ Page 7) the product.
- ▶ Undo the drain screw (1) with the sealing ring.
- ▶ Open all of the domestic hot water tap fittings that are connected to the product so that the product and line drain until they are completely empty.
- ▶ Leave the domestic hot water tap fittings and the drain screw open until the product is started up again when the risk of frost has passed.
- ▶ When subsequently filling the product, only start it up again once the water that flows out of the opened domestic hot water tap fittings has no bubbles after the cold-water isolation valve that is set on-site is opened.

8 Recycling and disposal

- ▶ The competent person who installed your product is responsible for the disposal of the packaging.

Disposing of the product



■ If the product is labelled with this mark:

- ▶ In this case, do not dispose of the product with the household waste.
- ▶ Instead, hand in the product to a collection centre for waste electrical or electronic equipment.

Disposing of batteries



■ If the product contains batteries that are labelled with this mark:

- ▶ In this case, dispose of the batteries at a collection point for batteries.
 - ◁ **Prerequisite:** The batteries can be removed from the product without causing any destruction. Otherwise, the batteries are disposed of together with the product.
- ▶ In accordance with the legal regulations, used batteries must be returned since batteries may contain substances that are harmful to health and the environment.

Supplier**Vaillant Group International GmbH**

Berghauser Strasse 40 ■ D-42859 Remscheid

Tel. +49 2191 18 0

www.vaillant.info



0020271966_01

Publisher/manufacture**Vaillant GmbH**

Berghauser Str. 40 ■ D-42859 Remscheid

Tel. +49 2191 18 0 ■ Fax +49 2191 18 2810

info@vaillant.de ■ www.vaillant.de

© These instructions, or parts thereof, are protected by copyright and may be reproduced or distributed only with the manufacturer's written consent.

Subject to technical modifications.